Erasing an iPad

Last verified by Andrew Snodgrass on 08-05-2022

1. Go to Settings > General > Transfer or Reset iPad.



2. Tap Erase All Content and Settings.



3. The iPad will now erase and restart.



4. Once the iPad is done erasing, it will restart at the language selection screen, push the home button.



5. Select English.



6. Select United States.

7. Select Set Up Manually.



8. On the Wi-Fi network selection screen, scroll to the bottom and select use cellular. **DO NOT CONNECT TO THE FUELCLOUD WI-FI NETWORK.**




LTE 92%
Back
Choose a Wi-Fi Network
ApplusOBD
CS88-1050
FuelCloud
FuelCloud SAT
NW Rentals
Odell Wifi
Choose Another Network
Use Cellular Connection
Set up your iPad using cellular data if your Wi-Fi network is not available.

9. The iPad will then activate with Apple's server. This can take serval minutes.



10. After the iPad has been activated, the iPad will ask to enroll in the FuelCloud MDM. Select Next in the top right.

11. Enrolling in the FuelCloud MDM can take several minutes.



12. Once the iPad is enrolled in the FuelCloud MDM, select Enable Location Services.



13. The iPad will now launch to the home screen and download the FuelCloud app.



14. The FuelCloud app be greyed out until it has finished downloading and installing. Once done the app can be used. 

Note: Above screenshots were recorded using iPadOS 15.6.